






WALL LT

Instrukcja montażu


Installation instructions
Instructions de montage
Montageanleitung

IP54


230 V
50 Hz




PL - Wyłączyć zasilanie przed wymianą lampy.
UK - Disconnect the unit before changing the lamp.
F - Debrancher l'appareil avant de changer la lampe.
D - Von den Auswechseln der lampe die Leuchte von der Netzspannung trennen.



①



②



③

