








DL 160

Instrukcja montażu


Installation instructions
Instructions de montage
Montageanleitung

IP20

230 V
50 Hz




PL - Wyłączyć zasilanie przed wymianą lampy.
UK - Disconnect the unit before changing the lamp.
F - Débrancher l'appareil avant de changer la lampe.
D - Von den Auswechseln der lampe die Leuchte von der Netzspannung trennen.




P.U.H. "IMPERIAL" ZPCHr Sp.J. Donat Król, Dariusz Król
ul. Kofobrzeńska 8E, 78-200 Białogard
tel. +48 94 312 78 20, tel./fax. +48 94 312 78 69
email: office@imperial.pl
NIP 672-000-62-93

imperial®


①



②



③



P.U.H. "IMPERIAL" ZPCHr Sp.J. Donat Król, Dariusz Król
ul. Kofobrzeńska 8E, 78-200 Białogard
tel. +48 94 312 78 20, tel./fax. +48 94 312 78 69
email: office@imperial.pl
NIP 672-000-62-93

imperial®