




DL 400

Instrukcja montażu


Installation instructions
Instructions de montage
Montageanleitung

IP44

230 V
50 Hz





PL - Wyłączyć zasilanie przed wymianą lampy.
UK - Disconnect the unit before changing the lamp.
F - Debrancher l'appareil avant de changer la lampe.
D - Von den Auswechseln der lampe die Leuchte von der Netzspannung trennen.




P.U.H. "IMPERIAL" ZPCHR Sp.J. Donat Król, Dariusz Król
ul. Kofobrzaska 8E, 78-200 Białogard
tel. +48 94 312 78 20, tel./fax. +48 94 312 78 69
email: office@imperial.pl
NIP 672-000-62-93

imperial®

1




2




max. 12mm
min. 1mm


3




4



5



PL - Wyłączyć zasilanie przed wymianą lampy.
UK - Disconnect the unit before changing the lamp.
F - Debrancher l'appareil avant de changer la lampe.
D - Von den Auswechseln der lampe die Leuchte von der Netzspannung trennen.



P.U.H. "IMPERIAL" ZPCHR Sp.J. Donat Król, Dariusz Król
ul. Kofobrzaska 8E, 78-200 Białogard
tel. +48 94 312 78 20, tel./fax. +48 94 312 78 69
email: office@imperial.pl
NIP 672-000-62-93

imperial®